

## Wired and Wireless scanner Cleaning

### DS8100 Series for Healthcare and CS60 Series for Healthcare

3% Hydrogen Peroxide and 97% Water Solution	Metrex CaviWipes
10% Bleach (Sodium Hypochlorite 0.55%) and 90% Water Solution*	Metrex CaviWipes 1
91% Isopropyl Alcohol and 9% Water Solution	Mild Dish Soap
Azowipe	PDI Easy Screen® Cleaning Wipe
BruLin BruTab 6S Tablets*	PDI Sani-Cloth AF3 Germicidal Disposable Wipe
Clinell Universal Sanitizing Wipes	PDI Sani-Cloth Bleach Germicidal Disposable Wipe*
Clinell Universal Wipes	PDI Sani-Cloth HB Sani-Germicidal Disposable Wipe
Clorox Dispatch Hospital Cleaner Disinfectant Towels with Bleach*	PDI Sani-Cloth Plus Germicidal Disposable Cloth
Clorox Formula 409 Glass and Surface Cleaner	PDI Super Sani-Cloth Germicidal Wipe
Clorox Healthcare Bleach Germicidal Wipes*	Progressive Products Wipes Plus
Clorox Healthcare Hydrogen Peroxide Wipes	Sani Professional Disinfecting Multi-Surface Wipes
Clorox Healthcare Multi-Surface Quat Alcohol Wipes	Sani-Hands® Instant Hand Sanitizing Wipes
Diversey D10 Concentrate Detergent Sanitizer	SC Johnson Windex Original Glass Cleaner with Ammonia-D
Diversey Dimension 256 Neutral Disinfectant Cleaner	Spartan Hepacide Quat II
Diversey Oxivir Tb Wipes	Sterets Alcowipe
Diversey Virex II 256 One-Step Disinfectant Cleaner	Steris Coverage Plus Germicidal Surface Wipes
Medipal Alcohol Wipes	Veridien Viraguard
Metrex CaviCide	WipesPlus Hospital/Surgical Wipes
Metrex CaviCide 1	

\* Not for use on cradles

### Additional Periodic Deep Cleaning Maintenance

Keep your Zebra device and cradle in good working order with regular and comprehensive cleaning to remove the natural build-up of dirt that occurs with everyday use. Deep cleaning maintenance is recommended on a monthly basis.

#### 1. Scanner Exit Window:

- Wipe the scanner exit window with a lens tissue or other material suitable for cleaning optical materials such as eyeglasses.

#### 2. Charging Contacts

- Dip the cotton portion of a cotton-tipped applicator in isopropyl alcohol.
- Gently rub the cotton portion of the cotton-tipped applicator back and forth across the connector contacts of the Zebra device.
- Using a dry cotton-tipped applicator, rub across the connector contacts of the Zebra device back and forth several times.
- Carefully inspect and remove any cotton or other residue that remains on the connector.
- Allow the isopropyl alcohol to air dry, or dry with a soft lint-free cloth or towelette. Ensure electrical contacts are fully dry before reapplying power.

#### 3. Cradles and Battery Chargers

- Remove the power cable from the cradle or charger.
- Dip a cotton-tipped applicator in isopropyl alcohol.
- Gently rub the moistened cotton-tipped applicator along the pins of the connector. Slowly move the applicator back and forth from one side of the connector to the other.
- Rub all sides of the connector with the cotton-tipped applicator.
- Spray compressed air in the connector area by pointing the tube/nozzle about 1/2 inch (12.7 mm) away from the surface. (Caution: When using compressed air, follow the product manufacturer's directions for safe usage.)
- If grease or other types of debris are found on other areas of the cradle, use a lint free cloth and isopropyl alcohol or a pre-moistened alcohol wipe to remove.
- Inspect and remove any residue (e.g., cotton, cloth, etc.) that may have attached to the connector during the cleaning process.